

## Line Shut-Off Valve RLB

### Product information



To be used with the Lifting Bag RLB system.

- If the safety valve starts evacuating the pressure earlier than its set value due to foreign object penetration, rotate the head of the safety valve (blow off valve) counter-clockwise to let the compressed air escape.
- If the foreign object is still in the safety valve, replace the valve.
- If you observe damage on the surface of Lifting Bag such as cuts and punctures, don't try to repair.
- Don't use damaged products.