

GB Instruction for use
FR Manuel d'utilisation

POWERTEX



Mechanical Rack Jack PRJ-S2

User Manual



POWERTEX Mechanical Rack Jack PRJ-S2 Instruction for use (GB) (Original instructions)

Read and understand this instruction manual before using the product. Failure to read these instructions may result in personal injury and/or property damage. Retain this instruction manual during the whole lifespan of the product.


Product description

The POWERTEX mechanical rack jack PRJ-S2 is made from high strength steel and is available in several capacities. The lifting mechanism is well protected inside a steel housing preventing it from damages and dirt. The jack is intended to lift loads using only hand force by operating the crank handle. Brake pawls will hold the load in position when the handle is released. PRJ-S2 jacks are designed to be loaded on the top support or on the lower toe support. The jacks are intended to be used to temporarily lift the load until it can be landed safely on a stable support.

Standard applied: EN 1494

Proof load testing: Each jack has been tested 1,25 x WLL at the factory prior delivery.

Temperature range: -20°C up to +50°C.



Data

Part code	WLL (ton)	Crank force to lift full load N	Weight (kg)
16.35PRJS2015	1,5	186	13,5
16.35PRJS2030	3	250	21,2
16.35PRJS2050	5	245	28,5
16.35PRJS2100	10	392	46,8

Dimensions

WLL (ton)	A mm	B x G mm	Lift height C mm	Heel height D mm	E mm	F mm	H mm	I mm	K mm	T mm
1,5	82	100x110	600-900	60-360	55	48	225	190	163	113
3	83	130x140	730-1080	70-420	60	45	250	200	197	127
5	106	140x170	730-1080	80-430	71	68	275	239	189	127
10	124	140x170	800-1210	85-495	86	76	300	293	250	248

Static test coefficient: WLL x 1,25

Generally according to EN 1494

General instructions for safe work with jacks

Lifting operations using jacks must only be conducted by trained personnel.

Always follow national safety regulations.

Operate the equipment in accordance with the information in these operating instructions.

Check the equipment prior each usage and use only equipment being in perfect working order.

Important to use the jack on a substrate with sufficient load bearing capacity, else it could sink or topple and potentially drop the load.

Always be conscious of safety and aware of hazards when working with jacks as elevated heavy loads are involved.

Plan the lift carefully and ensure that the jack will be stable during the whole lifting operation.

Never exceed the working load limit WLL stated on the product identification plate.

Always lift smoothly and avoid shock loading as this could damage the jack.

Always lift with the load centered on the support areas.

During lifting and lowering movements always observe the movement of the load and lifting equipment.

When lifting the load with the toe support, the force transmission should be as close to the rack housing as possible.

If any problem with the equipment occur during use, the work must be immediately stopped, and the jack taken out of service for a thorough examination. Carry out necessary repairs before continuing to work!

Do not leave the load suspended without supervision.

Do not allow persons or body parts under a raised load until it has been properly supported by jack stands or other suitable supports.

Do not allow persons onboard the load being lifted.

Use only hand force to operate the handle, extensions are not allowed.

Transport the jack protected against impacts and shocks, falling over or toppling.

Keep a record of all jacks and other lifting equipment

A thorough inspection should be conducted and recorded by a competent person at least every 12-month ensuring that the jack is free from defects and that it operates perfectly.

Usage exclusions

Not intended for permanent installations

Not intended to be used on vibrating loads


Not intended for use in explosive environments.

Not intended for use in chemical or corrosive environments.

Not intended for lifting hazardous loads.

Description of parts:

- 1) Base
- 2) Lever
- 3) Upper support stand
- 4) Lower support stand
- 5) Upper ratchet pawl
- 6) Lower ratchet pawl
- 7) Axle ring

**Operation**

Place the jack under the load on a hard level surface. Place the jack so that the load can be firmly supported by the lower (4) or upper (3) support stand. Rotate the lever (2) clockwise by hand to lift the load and counterclockwise to lower the load. Never hold the gear rack while operating the jack as the housing will travel along the rack.

Lifting with several jacks

Lifting with 2 or more jacks simultaneously represent a high-risk operation.

There is a risk for uneven load distribution and overloading as one jack may take all the load whilst others become unloaded. This type of lifts must therefore be planned and supervised by a competent person with experience in this type of lifting.

Maintenance and inspections**Daily inspection and storage**

Before each use, a visual inspection shall be made for any abnormal conditions, such as cracked welds, damage, bent, worn, loose or missing parts or illegible identification plate. Also check that the jack movement is operating smoothly. If any defect is detected or malfunction occur, the jack should be removed from service immediately and thoroughly inspected by a competent person. The jack should be thoroughly inspected immediately if it is suspected to have been subjected to abnormal loading or shock loading. Always store your jack in the fully lowered position.

Thorough inspection

At least every 12 months or shorter period if required by the working conditions a thorough inspection should be made by a competent person where the equipment is inspected for any damages such as missing parts, information plate being illegible, deformations, cracks and wear that may affect safety. Repairs needed shall be performed by an authorized customer service representative. Lubrication is needed to secure smooth function and to extend lifetime. Lubricate the gear rack regularly with heavy-duty water-resistant bearing grease and a light oil for the moveable crank house parts. The results of the thorough inspections should be recorded.

End of use/Disposal

Rack jacks shall always be sorted/scrapped as general steel scrap.
Your POWERTEX distributor will assist you with the disposal, if required.

Cric mécanique à crémaillère POWERTEX PRJ-S2

Notice d'utilisation (FR)

Lisez et assurez-vous de bien comprendre ce mode d'emploi avant d'utiliser le produit. Le non-respect de ces instructions peut entraîner des blessures corporelles et/ou des dommages matériels. Conservez cette notice d'utilisation pendant toute la durée de vie du produit.


Description du produit

Le cric mécanique à crémaillère Powertex PRJ-S2 est fabriqué en acier haute résistance et plusieurs capacités sont disponibles. Le mécanisme de levage est protégé à l'intérieur d'un carter en acier, ce qui l'empêche d'être endommagé et sali. Le cric est destiné à soulever des charges en utilisant uniquement la force manuelle en actionnant la manivelle. Les cliquets de frein maintiennent la charge en position lorsque la poignée est relâchée. La capacité des crics PRJ-S2 est identique pour une charge levée sur la tête ou sur la patte. Les crics sont destinés à être utilisés pour soulever temporairement la charge jusqu'à ce qu'elle puisse être posée en toute sécurité sur un support stable.

Norme appliquée: EN 1494

Test de charge de preuve: Chaque cric a été testé à 1,25 x CMU à l'usine avant la livraison.

Température d'utilisation: -20°C à +50°C.



Données

Code	CMU (tonne)	Force de la manivelle sous pleine charge N	Poids (kg)
16.35PRJS2015	1,5	186	13,5
16.35PRJS2030	3	250	21,2
16.35PRJS2050	5	245	28,5
16.35PRJS2100	10	392	46,8

Dimensions

CMU (ton)	A mm	B x G mm	Hauteur de levée C mm	Hauteur patte D mm	E mm	F mm	H mm	I mm	K mm	T mm
1,5	82	100x110	600-900	60-360	55	48	225	190	163	113
3	83	130x140	730-1080	70-420	60	45	250	200	197	127
5	106	140x170	730-1080	80-430	71	68	275	239	189	127
10	124	140x170	800-1210	85-495	86	76	300	293	250	248

Coefficient d'essai statique : CMU x 1,25

Généralement selon la norme EN 1494

Instructions générales pour travailler en toute sécurité avec des crics

Les opérations de levage à l'aide de crics ne doivent être effectuées que par du personnel qualifié.

Suivez toujours les réglementations nationales en matière de sécurité.

Faites fonctionner l'équipement conformément aux informations contenues dans le présent mode d'emploi.

Vérifiez le matériel avant chaque utilisation et n'utilisez que du matériel en parfait état de fonctionnement.

Il est important d'utiliser le cric sur un support ayant une capacité de charge suffisante, sinon il risque de s'écraser ou de basculer et de faire tomber la charge.

Soyez toujours soucieux de la sécurité et conscient des risques lorsque vous travaillez avec des crics, car les charges soulevées sont lourdes.

Planifiez soigneusement le levage et assurez-vous que le cric sera stable pendant toute l'opération.

Ne dépassez jamais la charge maximale d'utilisation CMU indiquée sur la plaque d'identification du produit.

Soulevez toujours en douceur et évitez les chocs car cela pourrait endommager le cric.

Soulevez toujours avec la charge centrée sur les zones d'appui.

Pendant les opérations de levage et de descente, observez toujours le mouvement de la charge et de l'équipement de levage.

Lors d'un levage sur la patte, la charge doit être aussi proche que possible du boîtier de la crémaillère.

En cas de problème avec l'équipement pendant l'utilisation, le travail doit être immédiatement arrêté et le cric mis hors service pour un examen approfondi. Effectuez les réparations nécessaires avant de continuer à travailler !

Ne laissez pas la charge soulevée sans surveillance.

Ne laissez pas des personnes ou des parties du corps sous une charge soulevée tant que celle-ci n'a pas été correctement stabilisée par des crics ou d'autres supports appropriés.

Ne pas autoriser des personnes sur la charge à soulever.

Utilisez uniquement la force manuelle pour actionner la poignée. Des extensions ne sont pas autorisées.

Transportez le cric avec une protection contre les impacts et les chocs, la chute ou le basculement.

Tenir un registre de tous les crics et autres équipements de levage.


Une inspection approfondie doit être effectuée et enregistrée par une personne compétente au minimum tous les 12 mois pour s'assurer que le cric est exempt de défauts et qu'il fonctionne parfaitement.

Interdictions d'utilisation

Non destiné aux installations permanentes Non destiné à être utilisé sur des charges oscillantes
 Non destiné à être utilisé dans des environnements explosifs.
 Non destiné à être utilisé dans des environnements chimiques ou corrosifs.
 Non destiné au levage de charges dangereuses.

Description des pièces:

- 1) Base
- 2) Levier
- 3) Tête
- 4) Patte
- 5) Cliquet supérieur
- 6) Cliquet inférieur
- 7) Bague d'essieu



Opération

Placez le cric sous la charge sur une surface solide. Placez le cric de manière à ce que la charge puisse être fermement soutenue par le support inférieur (Patte 4) ou supérieur (Tête 3). Tournez le levier (2) manuellement dans le sens des aiguilles d'une montre pour soulever la charge et dans le sens inverse pour l'abaisser. Ne tenez jamais la crémaillère lorsque vous utilisez le cric, car le boîtier se déplacera le long de la crémaillère.

Levage avec plusieurs crics

Le levage à l'aide de deux ou plusieurs crics simultanément représente une opération à haut risque. Il existe un risque de répartition inégale de la charge et de surcharge, car un cric peut prendre toute la charge alors que les autres sont déchargés. Ce type de levage doit donc être planifié et supervisé par une personne qualifiée ayant une expérience dans ce type de levage.

Maintenance et inspections

Inspection et stockage au quotidien

Avant chaque utilisation, un contrôle visuel doit être effectué pour détecter toute anomalie, telle que des soudures fissurées, des dommages, des déformations, de l'usure, des pièces perdues ou manquantes ou une plaque d'identification illisible. Vérifiez également à vide que le cric fonctionne bien. Si un défaut est détecté ou si un dysfonctionnement se produit, le cric doit être immédiatement mis hors service et inspecté minutieusement par une personne habilitée. Le cric doit être immédiatement inspecté minutieusement s'il est suspecté d'avoir été soumis à une charge anormale ou à un choc. Rangez toujours votre cric en position entièrement abaissée.


Une inspection minutieuse

Tous les 12 mois minimum, ou moins si les conditions de travail l'exigent, une inspection approfondie doit être effectuée par une personne compétente afin de vérifier que l'équipement ne présente pas de dommages tels que des pièces manquantes, une plaque d'information illisible, des déformations, des fissures ou une usure pouvant affecter la sécurité. Les réparations nécessaires doivent être effectuées par une société autorisée par le fournisseur. La lubrification est nécessaire pour garantir un fonctionnement sans heurts et pour prolonger la durée de vie. Lubrifiez régulièrement la crémaillère avec une graisse pour roulements résistante à l'eau et une huile légère pour les pièces mobiles du levier. Les résultats des inspections approfondies doivent être consignés.

Fin de l'utilisation/Destruction




Les crics à crémaillère doivent toujours être triés/détruits en tant que ferraille d'acier standard. Votre distributeur POWERTEX vous assistera dans la destruction, si nécessaire.




Pos	Description
1	Jack block
2	Screw
3	Rack
4	Axle
5	Elastic pin
7	Left bracket
8	Washer
9	Nut
10	Pawl spring
11	Lower ratchet pawl
12	Upper ratchet pawl
13	Axle ring
14	Ratchet wheel
15	Ratchet washer
16	Lever
17	Lock nut
18	Screw
19	Handle sleeve
20	Washer
21	Spring
22	Spring mandril
24	Axle
25	Gear
26	Axle seat
27	Washer
29	Elastic pin

POWERTEX Rack Jack PRJ-S2 – Spare parts 3 t



Pos	Description
1	Jack block
2	Screw
3	Rack
4	Axle
5	Elastic pin
7	Left bracket
8	Washer
9	Nut
10	Pawl spring
11	Lower ratchet pawl
12	Upper ratchet pawl
13	Axle ring
14	Ratchet wheel
15	Ratchet washer
16	Lever
17	Lock nut
18	Screw
19	Handle sleeve
20	Washer
21	Spring
22	Spring mandril
24	Axle
25	Gear
26	Axle seat
27	Washer
28	Sleeve
29	Elastic pin



Pos	Description
1	Jack block
2	Screw
3	Rack
4	Axle
5	Elastic pin
6	Axle
7	Left bracket
8	Washer
9	Nut
10	Pawl spring
11	Lower ratchet pawl
12	Upper ratchet pawl
13	Axle ring
14	Ratchet wheel
15	Ratchet washer
16	Lever
17	Lock nut
18	Screw
19	Handle sleeve
20	Washer
21	Spring
22	Spring mandril
23	Gear
24	Axle
25	Gear
26	Axle seat
27	Washer
28	Sleeve
29	Elastic pin

CertMax+

The CertMax+ system is a unique leading edge certification management system which is ideal for managing a single asset or large equipment portfolio across multiple sites. Designed by the Lifting Solutions Group, to deliver optimum asset integrity, quality assurance and traceability, the system also improves safety and risk management levels.

CertMax

Marking

The POWERTEX Mechanical Rack Jack is equipped with a RFID (Radio-Frequency IDentification) tag, which is a small electronic device, that consist of a small chip and an antenna. It provides a unique identifier for the block.

The POWERTEX Mechanical Rack Jacks are **CE** marked

Standard: EN 1494.



User Manuals

You can always find the valid and updated User Manuals on the web. The manual is updated continuously and valid only in the latest version.

NB! The English version is the Original instruction.

The manual is available as a download under the following link:
www.powertex-products.com/manuals




Product compliance and conformity

SCM Citra OY
Juvan Teollisuuskatui 25 C
02920 Espoo
Finland
www.powertex-products.com



POWERTEX



www.powertex-products.com